


# SED281THB-PA0C0G(P110N28AP-TH) Microwave Oven Explode Drawing



### R330YS/W Parts and Components List

Art.	Name	QTY	PART NUMBER	CODE
P01	door frame (S)	1	GAL-330P01001	AR
	door frame (W)	1	GAL-330P01002	AP
P02	door window	1	GAL-330P02001	AM
P03	fuse socket	1	GAL-330P03001	AA
P04	capacitor holder	1	GAL-243P04001	AA
P05	fan bracket	1	GAL-330P05001	AA
P06	fan blade	1	GAL-330P06001	AE
P07	door (with inlays)	1	GAL-330P07001	AP
P08	shielding board	1	GAL-330P08001	AA
P10	shaft (turntable hub)	1	GAL-330P10001	AC
P11	roller ring	1	GAL-330P11001	AH
P12	glass tray	1	GAL-330P12001	AR
P13	splash shield (waveguide cover)	1	GAL-330P13001	AB
P14	upper hinge	1	GAL-330P14001	AB
P16	cavity	1	GAL-330P16001	AZ
P17	label (S)	1	GAL-330P17001	*
	label (W)	1	GAL-330P17002	*
P18	outer enclosure (S)	1	GAL-330P18001	AV
	outer enclosure (W)	1	GAL-330P18002	AU
P21	lamp socket	1	GAL-243P21001	AA
P22	air duct	1	GAL-330P22001	AE
P23	microswitch mounting	1	GAL-330P23001	AB
P26	foot	2	GAL-243P26001	AB
P27	base plate	1	GAL-330P27001	AP
P28	lower hinge	1	GAL-330P28001	AB
P29	face board (S)	1	GAL-330P29001	AM
	face board (W)	1	GAL-330P29002	AM
P31	prop	1	GAL-330P31001	AB
P32	button spring	2	GAL-330P32001	AA
P33	button	1	GAL-330P33001	AD
P87	board seal	1	GAL-330P87001	AA
P114	fälke (in door frame)	1	GAL-330P114001	AC
P117	door hook	1	GAL-330P117001	AB
P118	door hook spring	1	GAL-330P118001	AA
P124	clamp holder	1	GAL-330P124001	AA
P126	mica flake	1	GAL-330P126001	AA
P288	magnetron bracket	1	GAL-330P122001	AB
C01	h.v. fuse	1	GAL-330C01001	AF
C02	h.v. diode	1	GAL-330C02001	AE
C03	h.v. capacitor	1	GAL-330C03001	AN

C04	wave filter	1	GAL-330C04001	AP
C05	fan motor	1	GAL-330C05001	AP
C06	lamp	1	GAL-243C06001	AE
C07	thermostat	1	GAL-243C07001	AD
C08	magnetron	1	GAL-330C08001	BE
C09	microswitch	1	GAL-243C09001	AE
C10	microswitch	1	GAL-243C10001	AE
C11	microswitch	1	GAL-243C11001	AE
C12	transformer	1	GAL-330C12001	BD
C13	wiring harness	1	GAL-330C13001	AN
C14	power cord	1	GAL-330C14001	AN
C15	turntable motor	1	GAL-330C15001	AH
C17	p.c board	1	GAL-330C17001	AZ
C18	thin film switch	1	GAL-330C18001	AH
B01	upper foam cushion	1	GAL-330B01001	*
B02	turntable cushion	1	GAL-330B02001	*
B03	plastic bag	1	GAL-330B03001	*
B04	manual	1	GAL-330B04001	AC
B05	protection film	1	GAL-330B05001	*
B06	plastic bag	1	GAL-330B06001	*
B07	lower cushion	1	GAL-330B07001	*
B08	carton (S)	1	GAL-330B08001	*
B08	carton (W)	1	GAL-330B08002	*
B09	paper card	1	GAL-330B09001	*
	fuse 12 amp	1	GAL330C0400101	AE

\* denotes not registered parts as it is packing material