

SONY



Sony
Remote Control

RMF-TX300A

CONTROLLING YOUR TV (English)

1. Press Power key to turn on the TV.
2. Press and hold [VOL(-)] key and [MIC] key for 2 seconds initiate pairing with TV.
3. All pairing transaction is behind the scene and no setup is required.

Specification

Operating Temperature: -10 degree - 40 degree

Battery Type: 2 AAA batteries